

VIEWING / DELETING SAVED TESTS

Functions are available by selecting the "SET" icon in the main menu.



And then select "VIEW/DELETE Record"



Menu choices include: "VIEW Test Records", "DELETE last Record", and "CANCEL"

Menu choices include: "VIEW Test Records", "DELETE last Record", and "CANCEL"



VIEW Test Records allows you to view any record in memory



DELETE Last Record is the only delete function the instrument offers.



NOTE: The computer software will allow you to download all test results from instrument memory, View them, Save them, and upload back into the instrument. See the software manual for details.